

Pinout Diagram: 6H1064

Switched Battery Positive

Ignition Coil Negative

Input Signal Positive

Ballast Resistor

Input Signal Negative

Case Ground

